
Applications

























TianTai Zhenxing Filtech Co., Ltd

Headoffice & Factory Plant

No.51 - Huaqian Road - Pingqiao Huaqian Industry Zone - Tiantai City - Zhejiang Province - China

Contact: Hunter Ge Tel: +86 189 5850 9819 Fax: +86 576 8366 1619

E-mail: hunter@zhenxingfiltech.com

Guang Dong Office

Room 810 - Shangdu Commercial Square - South Fenghuang Road - Xiangzhou Area -

Zhuhai City - Guangdong Province - China

Tel: +86 0756 2117619 Fax: +86 0756 2117619 Mobile: +86 1332 2867 619

Contact : Mr. Ge

Website: www.zhenxingfiltech.com

European Sales Office

Vasagatan 35 - 41137 Gothenburg - Sweden

Tel: +46 31 788 0716 E-mail: info@jpsgroup.se



Filtration Purification Separation

Filter Cartridge

We are experts in designing and manufacturing:

Filter cartridges
Liquid and Air Filter Bags
Filter media
Filter systems

ZHENXING



TianTai Zhenxing Filtech Co,. Ltd



COMPANY PROFILE

Established In 1989 Zhenxing Filtech Co,. Ltd became an international well-known manufacturer of filter media and filter system for Air, Liquid and Gas Filtration and separation.

We have Non-woven felt production line, Woven steel mesh production line, Filter cartridge production line and Filter housing production line. We have invested in advanced test and analysis machines so we can offer our clients innovative and the best solutions. In cooperation with our clients we design and manufacture the filtration systems based on the clients design and requests. We want to create a long term relatiosnship with our customers and that is why we continually invest in the latest technology to meet the clients growing demand. Our manufacturing plant is located in Tiantai City, Zhejiang province approx. 3 hours from Shanghai and we have an European Sales Office so we can follow up projects locally in Europe. We invest in beeing a trusted and reliable partner within the air & liquid filtration industry.

We have a 2000m2 dust free production plant and we are ISO9001 certified with quality control systems in place to make sure the products and material we produce lives up to our clients high standards. All material is RoHS & REACH certified.



ISO Free of silicone oil RoHS REACH Food contact







SUS Sinter media Filter Cartridge(SST)


20 Chemical Compatibility Table


Test Equipment Center

Particle sizing counting system (0.15µm-200µm)











Pore size analyser

FTIR Spectrometer





CONTENTS

PVDF Filter Cartridge (PVDF)

10 Hydrophilic PVDF Filter Cartridge (HPVDF)

01	Polypropylene Filter Cartridge (LPP)	11	Glass Fiber Filter Cartridge (GF)
02	Polypropylene Filter Cartridge (IPP)	12	Mini Filter Cartridge (XP)
03	GPP Filter Cartridge (GPP)	13	Activated carbon filter Cartridge (ACF)
04	PES Filter Cartridge (LPS)	14	Melt blow filter cartridge (CP)
05	6 Filter Cartridge (PN)	15	Absolute Micron Melt blow Cartridge(JCP)
06	66 Filter Cartridge (PN66)	16	PP/Absorbent cotton fibre yarn wound around the core support Cartridge Filter (SP/SE/SG)
07	PTFE Filter Cartridge (PF)	17	Activated Filter Cartridge (CTO)
08	PTFE Filter Cartridge (HPF)	18	Stainless Steel Pleated Cartridge (SSF)

Polypropylene Filter Cartridge (LPP)

LPP pleated cartridge is fitted with double layered filter medium made of submicron polypropylene. With more than 0.5M²/10inch filter area and thermal weld of all polypropylene components, that makes this kind cartridge adhering to the USP Class VI and FDA CFR Title 21 criteria. It does not contain any binding agents, adhesives or additives. A high dirt-hold capacity and a low differential pressure, especially for filtering out impurities such as solid particles.

Features and Benefits:

Low differential pressure, high dirt-retention capacity and a long service life

Pleated depth filtration with maximum filtration area High flow rate

Great chemical compatibility and acid-base resistance for liquid filtration

A wide range of fine filters which is suitable for different industries

Technical data

Size:

OD: $\phi 69 mm$ ID: $\phi 33 mm$

Length: 5" 10" 20" 30" 40"

Composition:

Filter media: Polypropylene membrane

Support/Drain layer: Polypropylene Cage support/Adaptor: Polypropylene

Core support: Polypropylene/SUS

Sealing compound: Silicone, EPDM, NBR, Viton,

PTFE, Viton coated with PTFE

Feature:

PH: 1-13 Max Temperature: 80°

Max Pressure diff: 0.42Mpa/25℃, 0.1Mpa/80℃

Application:


Filters in water-treatment plants

Pre-filters in ultrapure water for the electronic industry

Drinking water for food and beverages

Process filters for acids and lyes

Filtration of inks for ink-jet applications
Liquid or gas filtration for biological products, compressed air



Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
	010=0.1μm	DOE=DOE	5=5in	S= Silicone	P=Polypropylene
	022=0 . 22μm	TF=222/PIN	10=10in	E=EPDM	G=SUS
	045=0 . 45μm	SF=226/PIN	20=20in	N=NBR	
LPP	1=1µm	TC=222/Cap	30=30in	V=Viton	
	3=3µm	SC=226/Cap	40=40in	T=PTFE	
	5 =5µm	GSF=226SUS/PIN		F=Viton coated with PTFE	
	10=10μm	GTF=222SUS/PIN			
	20=20µm				

Polypropylene Filter Cartridge (IPP)

The IPP cartridge is manufactured by superfine fiber polypropylene membrane in the thermal welding process. The scientific pore structure makes absolutely fine filter. The depth filter is of high dirt-retention capacity, which ensures the filtering effect and efficiency. IPP pleated cartridge is fitted with 1 layered filter medium made of submicron polypropylene and 2 layered support filament felt which absolute no fiber peeling off. With more than $0.5\text{M}^2/10\text{inch}$ filter area and the mic-weld of all polypropylene components, that make this kind of cartridge adhering to the USP Class VI and FDA CFR Title 21 criteria. Allowing absolute filter rations of 99.9 % particle retention. Do not contain binding agents, adhesives or additives. A high dirt-hold capacity and a low differential pressure, especially for filtering out impurities such as solid particles and special liquid can't accept any fibers from the cartridge mix into the liquid.

Features and Benefits:

Low differential pressures, high dirt-retention capacity and a long service life Pleated depth filtration with maximum filtration area

The scientific design for high flow rate

Great chemical compatibility and acid-base resistance for liquid filtration A wide range of filter Micron which is suitable for various industries

Technical data

Size:

OD: $\phi 69 mm$ ID: $\phi 33 mm$

Length: 5" 10" 20" 30" 40"

Composition:

Filter media: Polypropylene membrane

Support/Drain layer: Polypropylene
Cage support/Adaptor: Polypropylene
Core support: Polypropylene/SUS

Inner core: Polypropylene/Stainless steel
Sealing compound: Silicone, EPDM, NBR, Viton
PTFE, Viton coated with PTFE

Feature:

PH: 1-13 Max Temperature: 80°

Max Pressure diff: $0.42 \text{Mpa}/25^{\circ}\text{C}$, $0.1 \text{Mpa}/80^{\circ}\text{C}$

Application:

Filters in water-treatment plants

Pre-filters in ultrapure water for the electronic industry

Drinking water for food and beverages

Process filters for acids and lyes

Filtration of inks for ink-jet applications

Liquid or gas filtration for biological products, compressed air



Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
	010=0.1µm	DOE=DOE	5=5in	S= Silicone	P=Polypropylene
	022=0 . 22μm	TF=222/PIN	10=10in	E=EPDM	G=SUS
	045=0 . 45μm	SF=226/PIN	20=20in	N=NBR	
IPP	1=1µm	TC=222/Cap	30=30in	V=Viton	
		SC=226/Cap	40=40in	T=PTFE	
		GSF=226SUS/PIN		F=Viton coated with PTFE	
		GTF=222SUS/PIN			

0.02

GPP Filter Cartridge (GPP)

GPP pleated filter cartridges have a multi-layered filter configuration containing micro fibers structured along the flow direction from the outside towards the inside in decreasing filter rations. In this way GPP pleated filter cartridges combine the advantages of common depth filters with those of pleated filter medias. This multi-layered filter media structure also ensures a long service life and a high dirt-retention capacity.

Features and Benefits:

Low differential pressures, high dirt-retention capacity and a long service life

Multi-layers Pleated depth filtration with maximum filtration area

The scientific design for high flow rate

Great chemical compatibility and acid-base resistance for liquid filtration

A wide range of fine filters which is suitable for all industries

Technical Data

Size:

OD: φ69mm ID: ω33mm

5" 10" 20" 30" 40" Length:

Composition:

Polypropylene membrane Filter media:

Polypropylene Support/Drain layer: Cage support /Adaptor: Polypropylene Core support: Polypropylene/SUS

Sealing compound: Silicone, EPDM, NBR, Viton,

PTFE, Viton coated with PTFE

Feature:

PH: 1-13 80℃ Max Temperature:

Max Pressure diff: 0.42Mpa/25°C 0.1Mpa/80°C

Application:

Filters in water-treatment plants

Pre-filters in ultrapure water for the electronic industry

Drinking water for food and beverages - Process filters for acids and lyes


Filtration of inks for ink-jet applications

Liquid or gas filtration for biological products, compressed air

Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
	010=0.1μm	DOE=DOE	5=5in	S= Silicone	P=Polypropylene
	022=0 . 22μm	TF=222/PIN	10=10in	E=EPDME	G=SUS
	045=0.45μm	SF=226/PIN	20=20in	N=NBR	
GPP	1=1µm	TC=222/Cap	30=30in	V=Viton	
		SC=226/Cap	40=40in	T=PTFE	
		GSF=226SUS/PIN		F=Viton coated with PTFE	
		GTF=222SUS/PIN			





Flow Rate (L/min) water flow rate

PES Filter Cartridge (LPS)

PES asymmetric membrane filter cartridge is fitted with hydrophilic polyether sulphone membrane and filter rations from 0.04 to 1um. Producing in a clean room and without using any additives and surface active substances. FDA certified, integrity test approved, can be sterilised, preflushed. Low albumen and micro organism absorption.

Features and Benefits:

Absolute filtration efficiency Acid-proof alkaline and excellent chemical compatibility Low albumen and micro organism absorption No fiber migration with ultra pure water washing Filter Cartridge 100% pass integrity tested

Technical data

Size:

OD: φ69mm ID: φ33mm

Hydrophilic membrane without pre-wetting

5" 10" 20" 30" 40" Length:

Composition:

Filter media: PES membrane Support/Drain layer: Polypropylene Cage support/Adaptor: Polypropylene Core support: Polypropylene/SUS

Silicone, EPDM, NBR, Viton, Sealing compound:

PTFE, Viton coated with PTFE

Feature:

PH: 2-13 85℃ Max Temperature:

Max Pressure diff: 0.42Mpa/25°C 1Mpa/80°C

Application:

Electronic Industry: Filtration in ultra pure water and distilled water Liquid bacteria removal on beverage and food Beverage Industry:

Chemical raw materials' bacteria removal and filtration Vaccine, serum and biological products bacteria removal

0.45µm 0.65µm 0.05 0.04 W Da 0.03 원 0.02-0.01 60

Flow Rate (L/min) water flow rate

Name	Micron	Adapter	Length	Sealing Materials	Core support
	010=0.1µm	DOE=DOE	5=5in	S= Silicon	P=Polypropylene
	020=0 . 2µm	TF=222/PIN	10=10in	E=EPDM	G=SUS
	045=0 . 45μm	SF=226/PIN	20=20in	N=NBR	
LPS	065=0 . 65μm	TC=222/Cap	30=30in	V=Viton	
	1=1µm	SC=226/Cap	40=40in	T=PTFE	
		GSF=226SUS/PIN		F=Viton coated with PTFE	
		GTF=222SUS/PIN			

6 Filter Cartridge (PN)

Nylon 6 filter cartridge is fitted with Nylon 6 membrane and the outer cage is made of polypropylene. It is produced by thermal welding technology. The absolute filter nylon filter membrane ensures of 99.9 % particle retention. FDA certified, integrity test approved, can be sterilised, preflushed. Low albumen and micro organism absorption.

Features and Benefits:

Hydrophilic membrane without pre-wetting Absolute filtration efficiency

Alkali resistant but no acid, excellent oil and solvent resistance

Great albumen and microorganism absorption
Uniformly distributed pure, strong mechanism and long

No fiber migration with ultra pure water washing Filter Cartridge 100% pass integrity tested

Technical data

Size:

OD: $$\phi69mm$$ ID: $$\phi33mm$$

Length: 5" 10" 20" 30" 40"

Composition:

Filter media: Nylon 6 membrane
Support/Drain layer: Polypropylene
Cage support/Adaptor: Polypropylene
Core support: Polypropylene/SUS

Sealing compound: Silicone, EPDM, NBR, Viton, PTFE,

Viton coated with PTFE


Feature:


PH: 6-14 Max Temperature: 85° C

Max Pressure diff: 0.42Mpa/25°C 0.1Mpa/80°C

Application:

Filtration in ultra pure water and distilled water Liquid bacteria removal on beverage and food Chemical raw materials bacteria removal and filtration Vaccine, serum and biological products bacteria removal





Flow Rate (L/min) water flow rate

Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
PN	010=0.10μm 020=0.20μm 045=0.45μm 065=0.65μm 1=1μm 3=3μm	DOE=DOE TF=222/PIN SF=226/PIN TC=222/Cap SC=226/Cap GSF=226SUS/PIN GTF=222SUS/PIN	5=5in 10=10in 20=20in 30=30in 40=40in	S= Silicone E=EPDM N=NBR V=Viton T=PTFE F=Viton coated with PTFE	P=Polypropylene G=SUS

66 Filter Cartridge (PN66)

Nylon 66 filter cartridge is fitted with Nylon 6 membrane and the outer cage is made of polypropylene. It is produced by thermal welding technology. The absolute filter nylon filter membrane ensures of 99.9 % particle retention. FDA certified, integrity test approved, can be sterilised, preflushed. Low albumen and micro organism absorption.

Features and Benefits:

Hydrophilic membrane without pre-wetting

Absolute filtration efficiency

Alkali resistant but no acid, excellent oil and solvent resistance

Great albumen and microorganism absorption
Uniformly distributed pure, strong mechanism and
long service life

No fiber migration with ultra pure water washing Filter Cartridge100% pass integrity tested

Technical data

Size:

OD: $\phi 69mm$ ID: $\phi 33mm$

Length: 5" 10" 20" 30" 40"

Composition:

Filter media: Nylon 66 membrane
Support/Drain layer: Polypropylene
Cage support/Adaptor: Polypropylene

Core support: Polypropylene/SUS

Sealing compound: Silicone, EPDM, NBR, Viton,

PTFE, Viton coated with PTFE

Feature:


PH: 6-14 Max Temperature: 85°C

Max Pressure difference: 0.42Mpa/25°C 0.1Mpa/80°C

Application:

Filtration in ultra pure water and distilled water Liquid bacteria removal on beverage and food Chemical raw materials liquid bacteria removal and filtration

Vaccine, serum and biological products bacteria removal



Flow Rate (L/min) water flow rate

Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
	010=0.1µm	DOE=DOE	5=5in	S= Silicone	P=Polypropylene
	020=0.2µm	TF=222/PIN	10=10in	E=EPD	G=SUS
	045=0.45µm	SF=226/PIN	20=20in	N=NBR	
PN66	065=0.65µm	TC=222/Cap	30=30in	V=Viton	
	1=1.00µm	SC=226/Cap	40=40in	T=PTFE	
		GSF=226SUS/PIN		F=Viton coated with PTFE	
		GTF=222SUS/PIN			

05

30 40

50 60 70 80

PTFE Filter Cartridge (PF)

PTFE filter membrane is used and the core support is made of polypropylene material or the stainless steel. It is produced by thermal welding technology. The hydrophobic filter with strong acid and alkali resistance is usually used in organic solvents and gas filtration.

Features and Benefits:

Heat and ozone resistance

Absolutely bacteria removal in a wet or dry environment Strong acid and strong alkali resistance with excellent

chemical compatibility

Wonderful pyrogen control and biological safety No fiber migration with ultra pure water washing Filter Cartridge 100% pass integrity tested

Technical data

Size:

OD: $\phi 69 mm$ ID: $\phi 33 mm$

Length 5" 10" 20" 30" 40"

Composition:

Filter media: Polytetrafluoroethylene membrane

Support/Drain layer: Polypropylene
Cage support/Adaptor: Polypropylene
Core support: Polypropylene/SUS

Sealing compound: Silicone, EPDM, NBR, Viton, PTFE,

Viton coated with PTFE

Feature:

PH: 1-14 Max Temperature: 90° C

Max Pressure diff: 0.42Mpa/25℃ 0.1Mpa/80℃

Application:

Steam dust and bacteria removal

Ultra pure gas filtration


Compressed air sterile filtration

Air filtration in aseptic packaging.

Aggressive acids, bases and solvents

Tank vent, fermentation air





Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
PF	010=0.1μm 020=0.2μm 045=0.45μm 1=1μm	DOE=DOE TF=222/PIN SF=226/PIN TC=222/Cap SC=226/Cap GSF=226SUS/PIN GTF=222SUS/PIN	5=5in 10=10in 20=20in 30=30in 40=40in	S= Silicone E=EPDM N=NBR V=Viton T=PTFE F=Viton coated with PTFE	P=Polypropylene G=SUS
		GTF=222SUS/PIN			

PTFE Filter Cartridge (HPF)

HPF PTFE filter cartridge make with hydrophilic PTFE membranes are available in filter rations of 0.05 µm to 1.0 µm. The membrane material is highly porous and features a homogenous pore distribution. All construction support, adapter and end cap components are made of polypropylene and are thermally connected to the PTFE Membrane in clean rooms without the use of additives or surface-active substances, hydrophilic membrane, FDA certified, integrity test approved, can be sterilised, preflushed. Low albumen and micro organism absorption.

Features and Benefits:

Hydrophilic membrane without pre-wetting Strong acid and strong alkali resistance with excellent chemical compatibility

Unique micro pore structure for high flow rate No fiber migration with ultra pure water washing Filter Cartridge 100% pass integrity tested

Technical data

Size:

OD: $\phi 69 mm$ ID: $\phi 33 mm$

Length: 5" 10" 20" 30" 40"

Composition:

Filter media: Hydrophilic polytetrafluoroethylene membrane

Support/Drain layer: Polypropylene

Cage support/Adaptor: Polypropylene
Core support: Polypropylene/SUS

Sealing compound: Silicone, EPDM, NBR, Viton, PTFE,

Viton coated with PTFE

Feature:

PH: 1-14 Max Temperature: 90℃

Max Pressure diff: 0.42Mpa/25°C 0.1Mpa/80°C

Application:

Fibrinolytic enzyme and liquid filtration

Aggressive acids, bases and solvents

High temperature deionized water filtration - Corrosive liquid filtration

Strong oxidizing liquid filtration, mineral water, pure water

Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
	010=0.1μm 020=0.2μm 045=0.45μm	DOE=DOE TF=222/PIN SF=226/PIN	5=5in 10=10in 20=20in	S= Silicone E=EPDM N=NBR	P=Polypropylene G=SUS
HPF	1=1µm	TC=222/Cap SC=226/Cap GSF=226SUS/PIN GTF=222SUS/PIN	30=30in 40=40in	V=Viton T=PTFE F=Viton coated with PTFE	

07 08

PVDF Filter Cartridge (PVDF)

PVDF filter cartridge is made of Polyvinylidene fluoride membrane

Features and Benefits:

Great temperature and oxidation resistance

Good pollution resistance

Good chemical compatibility for various gas filtration

No fiber migration with ultra pure water washing

Filter Cartridge100% pass integrity tested

Technical data

Size:

OD: φ69mm ID: φ33mm

5" 10" 20" 30" 40" Length:

Composition:

Sealing compound:

Polyvinylidene fluoride membrane Filter media:

Support/Drain layer: Polypropylene Cage support/Adaptor: Polypropylene

Core support: Polypropylene/SUS

Silicone, EPDM, NBR, Viton, PTFE, Viton coated with PTFE

Feature:

PH: 1-13 Max Temperature: 90℃

Max Pressure diff: 0.42Mpa/25°C 0.1Mpa/80°C

Application:

Steam dust and bacteria removal

Ultra pure gas filtration

Compressed air sterile filtration

Air filtration in aseptic packaging - Aggressive acids, bases and solvents

Tank vent, fermentation air

Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
	020=0.2µm	DOE=DOE	5=5in	S= Silicone	P=Polypropylene
	045=0.45µm	TF=222/PIN	10=10in	E=EPDM	G=SUS
	065=0.65μm	SF=226/PIN	20=20in	N=NBR	
PVDF	1=1.00µm∙	TC=222/Cap	30=30in	V=Viton	
		SC=226/Cap	40=40in	T=PTFE	
		GSF=226SUS/PIN		F=Viton coated with PTFE	
		GTF=222SUS/PIN			



0.012 0.008 0.004 Flow Rate (m³/min) Air flow rate

Hydrophilic PVDF Filter Cartridge (HPVDF)

HPVDF filter cartridge is made of hydrophilic Polyvinylidene fluoride membrane

Features and Benefits:

Excellent resistance for high temperature, ozone,

oi**l**, etc

Good pollution resistance

Good chemical and climate resistance

No fiber migration with ultra pure water washing

Filter Cartridge100% pass integrity tested

Technical data

Size:

OD: φ69mm ID: φ33mm

5" 10" 20" 30" 40" Length:

Composition:

Sealing compound:

Filter media: Hydrophilic Polyvinylidene fluoride membrane

Support/Drain layer: Polypropylene

Cage support/Adaptor: Polypropylene

Core support: Polypropylene/SUS

Silicone, EPDM, NBR, Viton, PTFE,

Viton coated with PTFE

Feature:

PH: 1-13 Max Temperature: 90℃

Max Pressure diff: 0.42Mpa/25°C 0.1Mpa/80°C



© 0.04 0.03 0.02 0.01 Flow Rate (L/min) water flow rate

Application:

High-viscosity liquid filtration

Biological impurity and bacteria removal - Organic solvents filtration

Strong oxidizing liquids filtration, mineral water and pure water

Name	Micron	Adapter	Length	Sealing Materials	Core support
	020=0.2μm 045=0.45μm 065=0.65μm	DOE=DOE TF=222/PIN SF=226/PIN	5=5in 10=10in 20=20in	S= Silicone E=EPDM N=NBR	P=Polypropylene G=SUS
HPVDF	080=0.8μm 1=1.00μm	TC=222/Cap SC=226/Cap GSF=226SUS/PIN GTF=222SUS/PIN	30=30in 40=40in	V=Viton T=PTFE F=Viton coated with PTFE	

n ZHENYING

Glass Fiber Filter Cartridge (GF)

Glass fiber pleated cartridges are fitted with polyproplene cage support and polyproplene adapter. The Glass-fiber-micro-media is provided with a mesh support and drainage from polyproplene media. All material components are thermal bonded without the use of adhesives or binders.

Features and Benefits:

Inflexibility fiber and great dirt-retention capacity

High performance of absorbability and high interception ratio

High flow rate and low pressure loss

Acid and alkali resistance and strong oil resistance

Technical data

Size:

OD: ϕ 69mm ID: ϕ 33mm

Length: 5" 10" 20" 30" 40"

Composition:

Filter media: Superfine glass fiber membrane

Support/Drain layer: Polypropylene
Cage support/Adapter: Polypropylene
Core support: Polypropylene/SUS

Sealing compound: Silicone, EPDM, NBR, Viton, PTFE,

Viton coated with PTFE

Feature:

PH: 1-13 Max Temperature: 80° C

Max Pressure diff: 0.42Mpa/25 ℃ 0.1Mpa/80 ℃


Application:

Wine pre-filtration and clarification

High-viscosity liquid pre-filtration

Oil filtration and clarification - Air filtration for dust, water and oil removal

Carbon removal for raw materials - Biologic pre-filtration



Flow Rate (L/min) water flow rate

Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
GF	020=0.2μm 045=0.45μm 1=1μm 3=3μm	DOE=DOE TF=222/PIN SF=226/PIN TC=222/Cap SC=226/Cap GSF=226SUS/PIN GTF=222SUS/PIN	5=5in 10=10in 20=20in 30=30in 40=40in	S= Silicone E=EPDME N=NBR V=Viton T=PTFE F=Viton coated with PTFE	P=Polypropylene G=SUS

Mini Filter Cartridge (XP)

XP filter cartridge is fitted by polypropylene membrance. Each component is assembled together by thermal welding technology. With small flow, small adsorption capacity and small residue, it makes its best choice for laboratory test or small production shop.

Features and Benefits:

Small volume and Low differential pressures
Pleated depth filtration with maximum filtration area
Great chemical compatibility for various liquid filtration
A wide range of fine filters for different industries
Selection of various filter materials

Technical data

Size:

OD : $\phi 56mm \ \phi 42mm$

Length: 2.5" 5"

Composition:

Filter media: Polypropylene membrane, nylon membrane,

PES membrane, glass fiber

Support/Drain layer: Polypropylene

Cage support/Adaptor: Polypropylene

Core support: Polypropylene/SUS

Sealing compound: Silicone, EPDM, NBR Viton, PTFE,

Viton coated with PTFE

Feature :

PH: 1-13 Max Temperature: 80°

Max Pressure difference : 0.42Mpa/25 °C 0.1Mpa/80 °C

Application:

Filters in water-treatment plants

Pre-filters in ultrapure water for the electronic industry

Drinking water for food and beverages

Process filters for acids and lyes

Filtration of inks for ink-jet applications

Liquid or gas filtration for biological products, compressed air

opport is assembled to





Order Information

Name	Filter media	Adapter	Length	sealing compound materails
XP	PN=nylon PP=polyprop lene PES=PES PF=PTFE	H=Oring/Cap RC=216/Cap	2.5=2.5in 5=5in	P=Polypropylene S= Silicone E=EPDM N=NBR V=Viton

 $\qquad \qquad 12$

Activated carbon filter Cartridge (ACF)

Activated carbon absorbs a variety of impurities and can be used to reduce odor and taste substances, bacteria, VOCs, pesticides and general organic impurities, or to decolor fluids. There are two types: filters containing granulated carbon, and filters with porous activated carbon blocks extruded to form tubes. The maximum flow rates, contact times with the activated charcoal and thus the retention rates of these filters also depend on whether flow is axial or radial.

Features and Benefits:

High adsorption capacity

Low differential pressure and stable water flow

Good heat resistance

High mechanical performance and Easy to install and use

Technical data

Size:

OD: φ69mm ID: φ33mm

5" 10"20"30"40" Length:

Composition:

Filter materials: Activated carbon fiber

Support/Drain layer: Polypropylene

Cage support/Adaptor: Polypropylene

Core support: Polypropylene/SUS

Silicone, EPDM, NBR, Viton, PTFE, Sealing compound:

Viton coated with PTFE

Feature:

PH: 1-13 Max Temperature: 85℃

Max Pressure diff: 0.42Mpa/25°C 0.1Mpa/80°C


Application:

Organic solvents decolorization and filtration

Wine and beverage filtration

Liquid & gas filters for residual chlorine and organics





Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
ACF	1=1μm 5=5μm 10=10μm	DOE=DOE TF=222/PIN SF=226/PIN	5=5in 10=10in 20=20in 30=30in 40=40in	S= Silicone E=EPDM N=NBR V=Viton	P=Polypropylene G=SUS

Melt blow filter cartridge (CP)

The CP melt-blow cartridge is manufactured in the melt-blow process where by four different spray nozzles are used to combine fine and coarse continuous fibers to form a multilayer structure. The fine layers are situated on the inside of the depth filter structure; the coarse layers on the outside. Due to this four-level gradiation coarse particles are retained in the outer layers and finer particles in the inner layers. This construction ensures a long service life, high dirtretention capacity and low differential pressures.

Features and Benefits:

Great chemical compatibility

High dirt-retention capacity and long service life Various adapters allowed and is easy to install and use Made of 100% PP, no other additions

Technical data

Size :

OD: φ60mm φ130mm ID: φ28mm φ30mm 10" 20" 30" 40" Length:

Composition:

Filter media: Polypropylene Nylon fiber

Adaptor: Polypropylene Core support: Polypropylene

Sealing Ring: Silicone, EPDM, NBR, Viton

Feature:

PH: 1-13 Micron: 1µm-100µ

Max Temperature : 80℃

Max Pressure difference : $0.2Mpa/25^{\circ}C$ $0.1Mpa/80^{\circ}C$


Application:

Wine and water filtration

Pre-filters for reverse osmosis water - Filters in water-treatment

Industrial water and electroplating solution filtration - Filtration of various organic solvents





Name	Micron	Adapter	Length	Sealing Materials	Core support
СР	1=1μm 3=3μm 5=5μm 10=10μm 20=20μm 50=50μm	DOE=DOE TF=222/PIN SF=226/PIN SC=226/Cap TC=222/Cap W=Without washer	10=10in 20=20in 30=30in 40=40in	S= Silicone E=EPDM N=NBR V=Viton	P=Polypropylene

Absolute Micron Melt blow Cartridge(JCP)

The Absolute Micron Melt blow cartridge with absolute filtration rate is produced in the melt-blow process. The perforated surface offers an enlarged filter surface area as well as a better binding for the continuous fibers on the filter surface. The filter is structured with a consistent pore-structure which decreases towards the middle, allowing a construction without a core support in the centre. The WFMBA melt-blow cartridge can be delivered optionally with open ends on both sides or with standard adapter constructions. The perforated surface area with subsequent depth filter structure ensures a long service life, high dirt-retention capacity and low differential pressures.



Features and Benefits:

Great chemical compatibility Absolute filtration efficiency High dirt-retention and long service life Various adapters allowed and is easy to install and use Made of 100% PP, no other additions

Technical data

Size:

OD: φ60mm φ130mm φ28mm φ30mm ID: 10" 20" 30" 40" Length:

Composition:

Filter media: Polypropylene Adaptor: Polypropylene Polypropylene Core support:

Silicone, EPDM, NBR, Viton Sealing:

Feature:

PH: 1-13

Micron: 1μm-100μ Max Temperature: 80℃

Max Pressure diff: 0.2Mpa/25℃, 0.1Mpa/80℃

Application:


Wine and water filtration

Pre-filters for reverse osmosis water

Filters in water-treatment

Industrial water and electroplating solution filtration.

Filtration of various organic solvents



Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
JCP	AB1=1µm AB3=3µm AB5=5µm AB10=10µm AB20=20µm AB50=50µm	DOE=DOE TF=222/PIN SF=226/PIN SC=226/Cap TC=222/Cap W=Without washer	10=10in 20=20in 30=30in 40=40in	S= Silicone E=EPDM N=NBR V=Viton	P=Polypropylene

PP/Absorbent cotton fibre yarn wound around the core support Cartridge Filter (SP/SE/SG)

This kind of filter cartridges consist of a continuous fibre yarn, which is wound around a fixed core support. This yarn structure forms the filter layer with a corresponding layer thickness and depth filter effect. Due to the use of various wondering techniques, different thickness of yarn and tractive force during winding, the filter cartridges can be produced with a variety of fine filter rations.

Features and Benefits:

Great chemical compatibility

High flow rate and good dirt-retention capacity Honeycomb structure for high filtering pressure

A wide range of fine filters for different industries

Technical data

Size:

φ60mm φ130mm ID: φ28mm φ30mm 10" 20" 30" 40"

Composition:

Length:

Filter media: Polypropylene, Absorbent cotton, Glass fiber

Core support: Polypropylene/SUS

Feature:

PH: 1-13

Micron: 1μm-100μm

Max Temperature: Polypropylene 80°C,

Max Pressure diff: 0.2Mpa/25°C 0.1Mpa/80°C

Application:

Pre-filters for drinking water and mineral water

Pre-filters for liquid medicine

Industrial water and electroplating solution filtration - Pre-filtration for wine and beverage

0.03 0.02-0.01

Flow Rate (L/min) water flow rate

Name	Micron	Adapter	Length	Sealing Materials	Core support
SP/SE/SG	1=1μm 3=3μm 5=5μm 10=10μm 20=20μm 30=30μm 50=50μm	DOE=DOE TF=222/PIN SF=226/PIN W=Without washer	10=10in 20=20in 30=30in 40=40in	S= Silicone E=EPDM N=NBR V=Viton	P=Polypropylene G=SUS

Activated Filter Cartridge (CTO)

Activated carbon absorbs a variety of impurities and can be used to reduce odor and taste substances, bacteria, VOCs, pesticides and general organic impurities, or to decolor fluids. There are two types: filters containing granulated carbon and filters with porous activated carbon blocks extruded to form tubes.

Features and Benefits:

High adsorption capacity

Low differential pressure and stable water flow

No carbon powder releasing

High quality and good integrity

Self pollution-free, ensuring the filter safety

Technical data

Size:

Length: 5" 10" 20" 30" 40"

Composition:

Filter media: Activated carbon Coco Nut carbon

Adaptor : Polypropylene
Drain Net : Polypropylene

Sealing compound: Silicone EPDM, NBR, Viton, PTFE,

Viton coated with PTFE

Feature:

Micron: 5μm-10μm

Max Temperature : 55° C

Max Pressure diff : $0.40 Mpa/25 ^{\circ}$


Application:

Organic solvents decolorization and filtration

Wine and beverage filtration

Liquid & gas filters for residual chlorine and organics





Order Information

Name	Micron	Adapter	Length	Sealing Materials	Core support
СТО	5=5μm 10=10μm	DOE=DOE TF=222/PIN SF=226/PIN	5=5in 10=10in 20=20in 30=30in 40=40in	S=Silicone E=EPDM N=NBR V=Viton	P=Polypropylene

Stainless Steel Pleated Cartridge (SSF)

SSF Stainless steel pleated cartridges are robust and multi-functional sieve elements with an enlarged filter area due to the pleated structure. The SSF Stainless steel pleated cartridges are reverse-flushable and have cleanable surfaces. The stainless steel screens are available in 5 μm to 500 μm and are mounted on a stable core support made of stainless steel perforated sheet with end caps welded on after being pleated. Apart from the standard versions with double-sided open ends (DOE), custom-made filter cartridges with different diameters, lengths and end-cap configurations can be manufactured.

Features and Benefits:

High temperature, strong acid and strong alkali resistance
Large porosity for good filtration effect
Strong mechanical performance and long service life
Can be reused after washing to reduce the cost
Uniform pure size for absolute filter efficiency
A wide range of fine filters for different industries

Technical data

Size:

Length: 2.5" 5" 10" 20" 30" 40"

Composition:

Filter media: Single or multi-layer SUS mesh

Core/Cage support/Adaptor: 304/316SUS

Sealing compound : Silicone, EPDM, NBR, Viton, PTFE,

Viton coated with PTFE

Feature:

PH: 1-14

Micron : $0.45 \mu m\text{-}100 \mu m$

 $\begin{tabular}{lll} Max Temperature: & 480\,^\circ\!C \\ Max Pressure Difference: & 0.5Mpa \end{tabular}$

Application:

High temperature gas filtration - Strong acid alkali and corrosive solvent filtration

 $High\ temperature\ and\ high\ viscosity\ liquid\ filtration\ -\ Gas\ and\ liquid\ filtration\ under\ high\ temperature\ and\ high\ pressure$



Name	Micron	Adapter	Length	Sealing Materials	Core support
SSF	045=0.45μm 1=1μm 3=3μm 5=5μm 10=10μm 20=20μm 50=50μm	DOE=DOE GTC=222SUS/Cap GTF=222SUS/PIN GSF=226SUS/PIN GSC=226SUS/Cap Thread	5=5in 10=10in 20=20in 30=30in 40=40in	S=Silicone E=EPDM N=NBR V=Viton T=PTFE F=Viton coated with PTFE	304/316SUS









17



SUS Sinter media Filter Cartridge(SST)

SST Stainless steel pleated cartridges are robust and multi-functional sieve elements with Sinter mesh or Sinter powder filter media. The SST Stainless steel pleated cartridges are reverse-flushable and have cleanable surfaces. The stainless steel sinter media are available in 1μm to 500μm and are mounted on a stable core support made of stainless steel perforated sheet with end caps welded on after being pleated. Apart from the standard versions with double-sided open ends (DOE), custom-made filter cartridge is available.

Features and Benefits:

High temperature, strong acid and strong alkali resistance High dirt-retention capacity and good filtration effect It is of fast velocity and high flux Good chemical compatibility for liquid filtration A wide range of fine filters for different industries

Technical data

Size:

Length: 2.5" 5" 10" 20" 30" 40"

Composition:

Filter media: 304/316SUS Core/Cage support /Adaptor: 304/316SUS

Silicone, EPDM, NBR, Viton, PTFE, Sealing compound:

Viton coated with PTFE

Feature:

PH: 1-14

0.45µm-100µm Micron:

280℃ Max Temperature : Max Pressure Diff: 0.3Mpa


Application:

Steam filtration of high temperature gas Filtration in petrochemical industry Strong corrosive liquid and gas filtration

Liquid and gas filters under high temperature and high pressure

Order Information

Name	Micron	Adapter	Length	Sealing Materials
SST	045=0.45μm 1=1μm 3=3μm 5=5μm 10=10μm 20=20μm 50=50μm	DOE=DOE GTC=222SUS/Cap GTF=222SUS/PIN GSF=226SUS/PIN GSC=226SUS/Cap Thread	05=5in 10=10in 20=20in 30=30in 40=40in	S= Silicone E=EPDM N=NBR V=Viton T=PTFE F=Viton coated with PTFE





Chemical Compatibility Table

Chemical Name	Nylon	PES	PVDF	PTFE	PP	Silicone	Viton	EPDN
Benzene	LR	LR	-	NR	LR	NR	R	NR
Methylbenzene	LR	NR	LR	LR	LR	NR	R	NR
Xylene	NR	NR	NR	NR	NR	NR	R	NR
Carbon tetrachloride	LR	LR	LR	LR	LR	NR	R	NR
Trichloromethane	NR	NR	LR	LR	LR	NR	R	NR
Ethylenedichloride	LR	NR	LR	LR	LR	NR	LR	LR
TF Freon	LR	LR	LR	LR	LR	NR	R	NR
TMC Freon	LR	NR						
			LR	LR	LR	NR	LR	NR
Dichloromethane	NR	NR	LR	LR	LR	NR	LR	NR
Perchloroethylene	LR	LR	LR	LR	LR	NR	R	NR
Trichloroethylene	LR	LR	NR	LR	LR	-	R	-
Ethylene glycol	R	LR	R	R	R	R	R	R
Glycerin	R	LR	R	R	R	R	R	R
Propylene glycol	R	LR	R	R	R	R	R	R
Diethyl ether	NR	LR	LR	LR	LR	LR	NR	NR
Isopropyl ether	-	-	R	R	R	NR	NR	NR
Dioxane	R	-	R	R	R	NR	NR	R
Tetrahydrofuran	NR	NR	LR	LR	LR	NR	NR	R
AceticAcid	NR	NR	R	R	R	LR	NR	LR
Hydrochloric acid(strong)	NR	R	R	R	R	NR	R	LR
Hydrochloric acid(6N)	NR	R	R	R	R	NR	R	LR
	NR	-	R					NR
Nitrate(strong)				R	R	NR	R	
Nitrate(6N)	NR		R	R	R	LR	R	NR
Phosphoric acid(strong)	LR	-	R	R	R	NR	R	NR
Sulfate(strong)	NR	NR	R	LR	LR	NR	R	LR
Orthoboric acid	R	R	R	R	R	R	R	R
Hydrofluoric acid(6N)	NR	NR	NR	NR	NR	NR	R	NR
Amyl acetate	LR	-	R	LR	LR	NR	NR	LR
n-Butyl acetate	LR	-	R	LR	LR	NR	LR	R
Ethyl acetate	R	LR	R	R	R	R	LR	R
Methyl acetate	R	NR	R	R	R	_	NR	R
Isopropyl acetate	R	R	R	R	R	LR	NR	R
Amyl alcohol	R	R	R	R	R	NR	R	R
Benzyl alcohol 100%	NR	NR	R	NR	NR	LR	R	R
Butyl alcohol	R	R	R	R	R	NR	R	NR
Ethanol		R						
	R		R	R	R	R	R	R
Isopropanol	R	R	R	R	R	R	R	R
Methyl alcohol	R	R	R	R	R	R	R	R
Ammonium hydroxide	R	R	LR	R	R	R	R	LR
Potassium hydroxide(3N)	R	R	LR	R	R	LR	R	R
Sodium hydroxide(3N)	R	R	LR	R	R	R	R	R
Sodium hydroxide(6N)	R	R	NR	R	R	R	R	LR
Acetone	R	NR	LR	R	R	NR	NR	R
Cyclohexanone	NR	NR	NR	NR	NR	NR	NR	R
Methyl ethyl ketone	R	-	LR	R	R	NR	NR	R
Methyl isobutyl ketone	LR	NR	LR	R	R	NR	NR	LR
Cottonseed oil	R	-	R	R	R	R	R	LR
Lubricating oil	R	NR	R	R	R	R	R	R
Peanut oil	R	- D	R	R	R	R	R	LR
Sesame oil	R	R	R	R	R	R	R	R
Phenylamine	LR	NR	R	LR	LR	NR	R	R
Dimethylformamide	NR	NR	NR	R	R	R	NR	R
Formaldehyde 37%	R	R	R	R	R	R	NR	R
Gasoline	LR	LR	LR	LR	LR	NR	R	R
Hexane	LR	NR	LR	LR	LR	NR	R	NR
Kerosene	R	R	R	R	R	NR	R	NR
Phenol	R	NR	R	R	R	NR	R	NR
Turpentine	LR	LR	LR	LR	LR	NR	R	NR
Water	R	R	R	R	R	LR	R	R
Acetonitrile	LR	R	R	R	R	- LN	NR	R
Acetonitrile								
ACIVIONITINE	R	R	R	R	R	-	NR	R
Molybdenum sulfate	R		R	R	R	R		R

This chart is intended only as a reference